



Operating Instruction

JK802/804/808

Multi-channel Handheld Temperature Meter

Safety Summary



Warning



Danger :

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. In addition it violates safety standards of design, manufacture, and intended use of the instrument.

Disclaimer

The Jinko Instruments assumes no liability for the customer's failure to comply with these requirements.

Ground The Instrument

To avoid electric shock hazard, the instrument chassis and cabinet must be connected to a safety earth ground by the supplied power cable with earth blade.

DO NOT Operate In An Explosive Atmosphere

Do not operate the instrument in the presence of inflammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite hazard. Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

Keep away from live circuit

Operations not included in the manual are forbidden

The protection measurements will be failure while beyond the scope.



Warning: TO AVOID INSTRUMENT DAMAGED, PLEASE DO NOT PUT DC VOLT OR CURRENT IN THE TESR TERMINAL MAKE SURE THE CAPACITOR IS DISCHARGED BEFORE TESTING

Safety Sign:



Provide double insulation or reinforced insulation protection

Waste Electrical and Electronic Equipment (WEEE) order 2002/96/EC



Do not leave in the trash can

CERTIFICATION, LIMITED & LIMITATION OF LIABILITY

Changzhou Jinailian Electronic Technology Co.,Ltd (shortened form JINKO) certifies that this product met its published specifications at the time of shipment from the factory. Jinko further certifies that its calibration measurements are traceable to the People's Republic of China National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility or by the calibration facilities of other International Standards Organization members.

This Jinko instrument product is warranted against defects in material and workmanship for a period corresponding to the individual warranty periods of its component products. The warranty period is 1 year and begins on the date of shipment. During the warranty period, Jinko will, at its option, either repair or replace products that prove to be defective. This warranty extends only to the original buyer or end-user customer of a Jinko authorized reseller, and does not apply to fuses, disposable batteries or to any product which, in Jinko's opinion, has been misused, altered, neglected or damaged by accident or abnormal conditions of operation or handling.

For warranty service or repair, this product must be returned to a service facility designated by Jinko. The buyer shall prepay shipping charges to Jinko and the Buyer shall pay all shipping charges, duties, and taxes for products returned to Jinko from another country.

Jinko warrants that its software and firmware designated by Jinko for use with an instrument will execute its programming instruction when properly installed on that instrument. Jinko does not warrant that the operation of the instrument, or software, or firmware, will be uninterrupted or error free.

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. JINKO SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, WHETHER ARISING FROM BREACH OF WARRANTY OR BASED ON CONTRACT, TORT, RELIANCE OR ANY OTHER THEORY.

People's Republic of China
Jiangsu Province Changzhou Jinailian Electronic Technology Co.,Ltd
Oct. 2008
Rev.A1

Contents

Safety Summary.....	2
CERTIFICATION, LIMITED & LIMITATION OF LIABILITY.....	3
Contents.....	4
Installation and Setup Wizard.....	6
Packing List.....	6
Power Supply.....	6
Operation Environment.....	6
Cleaning.....	7
1.5 Replace Battery.....	7
1.6 Adjusting Tilt Stand.....	7
2. Overview.....	9
Overview.....	9
MainSpecification.....	9
MainFunction.....	9
FUNCTION.....	9
Sorting Setting.....	10
Correction Function.....	10
System Setup.....	10
Interface.....	10
3. Startup.....	11
Front Panel Summary.....	11
LCD Screen.....	12
Interface.....	13
Extern power and Battery.....	13
Charge Li Battery.....	14
Power up.....	14
Connection of the Thermocouple.....	14
4.[MEAS] Page.....	16
<MEAS DISPLAY>.....	16
CHAN 【01】.....	17
5.[SETUP]Page.....	18
<Setup>Page.....	18
[MODEL] Setting.....	18
[UNIT]Setting.....	19
[RATE] Setting.....	19
[BEEP] setting.....	19
[HIGH] setting.....	19
[LOW] setting.....	20
[FAT SET] setting.....	20
[INTERVAL.....	20
6.[SYSTEM]Page.....	22
<SYSTEM CONFIG> page.....	22
[DATA].....	22
[TIME].....	23
[LANGUAGE].....	23
[FILE].....	23
[TOUCH PANEL].....	24
[BRIGHTNESS].....	24
DIM DISPLAY [DIM].....	25
AUTO POWER OFF [APO].....	25
7.....	Rem
oteControl.....	27
USB-HID.....	27
Programming guide.....	27
Command set.....	28
Command packet.....	28
Notation Conventions and Definitions.....	29
Parameter types.....	30
Command Reference.....	30
MODELSubsystem.....	31

	BEEPSubsystem	31
	RATESubsystem	31
	UNIT SubSystem	31
	CHANON SubSystem	32
	HIGH SubSystem	32
	LOWSubSystem	32
	FETC? SubSystem	32
	SYST System SubSystem	33
	IDN? Subsystem	33
	RST Subsystem	33
	Error Subsystem	33
Specification		35
	General Specification	35
	Accuracies	36
	Dimension	37

1. Installation and Setup Wizard

This chapter provides the following information:

Packing List
Power Requirements
Operation Environment
Cleaning
Replace Battery

Adjusting Tilt Stand

Packing List

After you receive the instrument, carry out checks during unpacking according to the following procedure.

Check that the packing box or shock-absorbing material used to package the instrument has not been damaged.

Referring to the packing list, check that all packaged items supplied with the meter have been provided as per the specified options.

If damaged or accessories shortage, please contact the sales department or our agent.

Power Supply

The Handheld Temperature Meter only can use our configured AC Adapter JKL909 and Li-battery JKL805

AC Adapter

Input Voltage: 90V-260VAC, 49Hz~62Hz

Power: Max 10VA



Warning: Other model AC Adapter is forbidden. Only L909 and L805 rechargeable Li-battery can be used.

Operation Environment

Ensure the operation environment meets the following requirements Temperature Range: 0°C ~ 55°C,

Humidity: 23°C, <70%RH

Altitude: 0~2000m

Cleaning

Do not attempt to clean the internal of JK802/804/808



Warning:
Don't Use Organic Solvents (such as alcohol or gasoline) to clean the Instrument.

Use a dry cloth or a cloth slightly dipped in water to clean the casing.

Replace Battery

Build-in rechargeable Li-battery, battery has been installed in the instruments before factory. Change the battery according to the following steps:

Figure 1- 1 Battery Change



1. Use the screwdriver to loosen the screw in the battery cover and remove the cover.
2. Remove the plug on the old battery, plug a new one, main direction of the plug.
3. Put the new battery in the instrument, recover and tighten the screws.

Adjusting Tilt Stand

Two positions are provided: degree 60 and degree 45
45 Degree 45 can provide a better stability for the instrument

Figure 1- 2 Position of Degree 60



Folded up the bottom of the bracket to achieve degree 45 position

Figure 1- 3 Position of Degree 45

2. Overview

This chapter provides the following information:

Overview
Main Specification
Main Function

Overview

Thank you for purchasing JK802 /804 / 808 Multi-channel Handheld Temperature Meter

The JK802/804/808 adopts high-performance ARM microprocessor control, collects multi-channel temperature data simultaneously. The JK802/804/808 can be compatible with a variety of temperature sensors, fast response, data stability while with the burnout detection function. Also you can separately calibrate the data of each channel. True-color TFT liquid crystal display, keypad and touch screen double control. Use Li- battery supply power and USB communication. Switch in both English and Chinese.

Main Specification

Graduation: thermocouple J ,K, T, E, S, N, B

Basic Accuracy:see the appendix(accuracy table)

Measurement Range: -200.0℃~1800.0℃ (change according to different thermocouple type)

Resolution: 0.1℃

Channel:	802	2 channels
	804	4 channels
	808	8 channels

Main Function

FUNCTION

1. Comparator Setting
2. Speed Setting
3. Beep Setting
4. Baud Rate Setting
5. Temperature Unit Setting

Sorting Setting

Build-in sorting data, each temperature data can be set both up limit and low limit

Correction Function

Each channel data can be corrected by the user.

System Setup

- Keypad Lock Function
- Switch in Both Chinese and English
- Data File will Be Saved Automatically
- Touch Screen Setup
- Power Saving Mode

Interface

USB Host Port:

USB high-speed mode: 48 MHz, USD-HID Protocol, ASCII Transi

3. Startu p

This chapter describes:

Front Panel Summary
 LCD Screen
 Interface
 Extern power and Battery
 Power up
Connection of the Thermocouple

Front Panel Summary

Figure 3-1 Front Panel





Table 3-1 Description of the Front Panel

1	TFT-LCD Screen
2	Select Keys
3	MEA Measurement Key——Enter Measurement Page (Page 15:[MEAS] Page)
4	SYS System Key ——Enter System Setting Page (Page 20: [SYSTEM] Page)
5	Power On/Off Battery Charging Indicator
6	Sensor access terminal
7	 Background Brightness——30%,50%,70%, 100% Unlock the Keypad Lock
8	HOLD NULL
9	SETU Enter Setup (Page 17:[ETUP] page)

LCD Screen

Figure 3-2 LCD



Screen

Table 3-2 LCD Screen descriptions

1	The Page Title
2	The white fields are label; the yellow fields are list box.
3	Help and message information
4	Function Area, Use the select keys to select
5	Battery Percentage and Keypad Lock Indicators
6	Display the current sensor model
7	Displays the current temperature unit
8	Memory flag

Interface

Figure 3-3 Interface panel




Table 3-3 Interface panel description

1	Remote Control Interface(USB-HID)
2	USB Memory Interface
3	Power Adapter Jack(+9VDC)
4	RESET
5	MICROSD Memory Interface

Extern power and Battery

The Battery can only be charged by Power Adapter JKL909.

While using the external power supply, the power adapter is also charging the battery.


Figure 3-4 Power Adapter



3.4.1 Charge Li Battery

When the battery power is low, you could use the power adapter to charge the battery. The Power key is orange indicating while charging the battery.

Figure 3-5 Charging LED (Orange)



Attention! The key is also orange which charging even when the LCR meter is off previously.)

Power up

Press the Power key softly to start it.

Connection of the Thermocouple

JK802 having 2 input ports
JK804 having 4 input ports
JK808 having 8 input
ports

Figure 3-4 Thermocouple Terminals




Table 3-4 Interface baffle description

1	“+” positive pole of the thermocouple
2	“-”negative pole of the thermocouple



Warning : Do not exceed channel isolation voltage 100V, otherwise it will damage the instrument.

4. [MEAS] Page

This section includes all measure result display information.

<Measure Display>Page

<MEAS DISPLAY>

When press the [Meas] key, the <MEAS DISPLAY> page appears. <MEASURE DISPLAY> page mainly highlights the measurement results, and current sorting results will be displayed in different font and color.

The following measurement controls can be set:

Channel Setting

Figure 4-1 JK802<MEAS DISPLAY> Page



Figure 4-2 JK804 <MEAS DISPLAY> Page



Figure 4-3 JK808<MEAS DISPLAY> Page

测量显示		TC-H(°C) 23:26:38 72%	
01:	36.5	02:	36.1
03:	36.5	04:	36.0
05:	36.0	06:	36.4
07:	36.1	08:	36.5
测量显示页面		2016-06-17	
设置	系统		

CHAN [01]

Steps to Set Sensor Model

Step 1	Press[Meas] key to enter <MEASURE	
Step 2	Use the cursor keys to select[01]field	
Step 3	Use side soft keys to select	
	Soft key	Function
	OFF	Close the current channel
	ON	Open the current channel

*The same steps to close or open other channels

设置用户修正的步骤

Step 1	Press[Meas] key to enter <MEASURE	
Step 2	Use the cursor keys to select[01]field	
Step 3	Use side soft keys to select	
	Soft key	Function
	AMEND	Use touch screen to type in
	CLEAR	Delete amend value

*The same steps to correct other channel values

5. [SETUP]Page

This section includes all setup functions
At any time,press [SETUP]to enter <SETUP> page.
<SETUP> Page

<Setup>Page

In < SETUP > page, the Instrument does not display any results,testing is not in progress.

The setup includes

MODEL –Chose the type of the thermocouple

UNIT –Temperature Unit Setting

RATE – Sampling Rate

BEEP – Beep Setting


HIGH – High Limit

LOW – Low Limit

FAT SET – FAT Memory set

INTERVAL – Date Save Interval

Figure5- 1<Setup> Page



[MODEL] Setting

The model set includes :8 types thermocouple T , K , J , N , E , S , R , B
Steps to set the model

Step 1	Press [Setup] key to enter <SETUP>page	
Step 2	Use cursor keys to select[MODEL]field	
Step 3	Use soft key to select	
	Soft Key	Function
	TC-T	Setting the thermocouple T type
	TC-K	Setting the thermocouple K type
	TC-J	Setting the thermocouple J type

	TC-N	Setting the thermocouple N type
	TC-R	Setting the thermocouple R type
	TC-S	Setting the thermocouple S type
	TC-E	Setting the thermocouple E type
	TC-B	Setting the thermocouple B type

[UNIT]Setting

Units Includes:(°C),(K),(F)

Steps to set beep feature

Step 1	Press [Setup] key to enter <SETUP> page	
Step 2	Use cursor keys to select[UNIT]field	
Step 3	Use soft keys to select	
	Soft Key	Function
	(°C)	Degree Celsius
	(K)	Degree Kelvin
	(F)	Degree Fahrenheit

[RATE] Setting

The Rate set include: Slow, Med and Fast

Steps to set rate

Step 1	Press [Setup] key to enter <SETUP>page	
Step 2	Use cursor keys to select[RATE]field	
Step 3	Use soft keys to select	
	Soft Key	Function
	SLOW	Set the sampling rateto slow
	MED	Set the sampling rateto med
	FAST	Set the sampling ratetofast

[BEEP] setting

The Beep set include: OFF and ON.

Steps to Set the Beep:

Step 1	Press [Setup] key to enter <SETUP >page	
Step 2	Use cursor keys to select[UNIT]field	
Step 3	Use soft keys to select	
	Soft Key	Function
	OFF	Turn off the Beep feature
	ON	Turn on the Beep feature

[HIGH] setting

Steps to set Highlimit

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [1800.0] field	

Step 3	Use soft keys to select	
	Soft Key	Function
	UPPER VALUE	Use touch screen to type in
	RESET	Restore Defaults

[LOW] setting

Steps to set Lowlimit

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [-200.0] field	
Step 3	Use soft keys to select	
	Soft Key	Function
	UPPER VALUE	Use touch screen to type in
	RESET	Restore Defaults

[FAT SET] setting

Steps to set FAT

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [FAT SET] field	
Step 3	Use soft keys to select	
	Soft Key	Function
	MICRO SD	Select MicroSD Memory Card
	USB DISK	Select USB FAT Memory

[INTERVAL

Steps to set interval

Step 1	Press [Setup] key to enter < SETUP > page	
Step 2	Use cursor keys to select [INTERVAL]	
Step 3	Use soft keys to select	
	Soft Key	Function
	UPPER VALUE	Use touch screen to type in
	RESET	Restore Defaults

Note:

First select [USB DISK] or [MICRO SD] , and then insert the MICRO SD card or USB memory card, the instrument automatically starts recording data.

Example :

Instrument current time is :2013 -11-20 15:30:35

Memory created under the root directory folder name : 20131120 , file name : 153035.CSV

The data format is Float type, reserve 1 digit behind the decimal point, channels are separated by “ , ” .

MODEL-TC-T (°C)	CH01	CH02	CH03	CH04	CH05	CH06	CH07	CH08
2013-12-04 15:00:00	28.0	28.1	100.5	19.2	32.4	54.3	21.6	41.9
2013-12-04 15:00:05	28.1	28.0	100.4	19.2	32.4	54.2	21.5	42.0
2013-12-04 15:00:10	28.0	28.1	100.5	19.1	32.3	54.2	21.5	42.0
2013-12-04 15:00:15	28.0	28.1	100.5	19.2	32.4	54.2	21.5	42.0

6. [SYSTEM]Page

This section includes all system information.


At any time, press [SYST] key to enter [SYSTEM] page.

<SYSTEM CONFIG> page

Following information can be configured in the <SYSTEM CONFIG> page.

System date and time configuration [DATE/TIME]
 LANGUAGE
 FILE
 TOUCH PANEL
 BRIGHTNESS
 DIM DISPLAY
 APO – Auto Power Off

Figure 6-1 <SYSTEM SETUP> Page



[DATA]

Procedure to set data

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select[DATA]	
Step 3	YEAR INCR+	+1Year
	YEAR DECR-	-1Year
	MONTH INCR+	+1Month
	MONTH DECR-	-1Month

	DAY INCR+	+1Day
	DAY DECR-	-1Day

[TIME]

Procedure to set time

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select[TIME]	
Step 3	HOUR INCR+	+1Hour
	HOUR DECR-	-1Hour
	MINUTE INCR+	+1Minute
	MINUTE DECR-	-1Minute
	SECOND INCR+	+1Second
	SECOND DECR-	-1Second

[LANGUAGE]

You can switch system language in both Chinese and English.

Procedure to change language

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select[LANGUAGE]	
Step 3	中文 (CHS)	Switch into Chinese
	ENGLISH	Switch into English

[FILE]

Procedure of file setting

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select [FILE] field	
Step 3	AUTO	All parameters set by user will be in saved
	IGNORED	The parameters will be lost after power off
	SAVE NOW	All parameters set by user will be in saved

[TOUCH PANEL]Tip
s

The LCR meter can work well without touch panel. But you cannot type number without touch panel. When you need to input numbers, the touch panel will be activated even it is shut down in system setting.


Procedure of setting touch panel

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select [TOUCH PANEL] field	
Step 3	ENABLE	Enable touch panel
	DISABLE	Disable touch panel
	CALIBRATE	Calibrate touch panel
	RESET	Reset touch panel data

Procedure to calibrate touch panel

Tips

You will need a screen pen to calibrate touch pane.
Do not use your finger!

Step 1	Press[SYST]key to enter<SYSTEM CONFIG> page.
Step 2	Select[TOUCH PANEL]soft key
Step 3	Select[CALIBRATE]soft key
Step 4	Use a screen pen to click screen softly to start calibration
	
Step 5	Tap the middle of the circle with a pen on Left-Up corner. Then tap the middle of the circle with a pen on the Right-
Step 6	Click on the screen softly to exit.


[BRIGHTNESS]

Four degrees of brightness 30%,50%,70%,100%

Tip
s

If powered by external power, the brightness is 100%.
If powered by battery, the low brightness can make the meter work longer.

Also, press  to change the brightness. Figure6-2The Brightness key



Procedure to change brightness

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select [BRIGHTNESS] field.	
Step 3	30%	30% of full brightness
	50%	50% of full brightness
	70%	70% of full brightness
	100%	Full brightness

DIM DISPLAY [DIM]

Procedure to dim display:

Step 1	Press [SYST] key to enter<SYSTEM CONFIG> page.	
Step 2	Select [DIM DISPLAY]	
Step 3	5 minutes	5 minutes later, brightness becomes 30%
	10 minutes	10 minutes later, brightness becomes
	20 minutes	20 minutes later, brightness becomes
	30 minutes	30 minutes later, brightness becomes
	OFF	Dim display off

Tips: Timer will be reset when press any keys or touch screen.

AUTO POWER OFF [APO]

Procedure of set auto power off:

Step 1	Press [SYST] to enter<SYSTEM CONFIG> page.	
Step 2	Select[APO]	
Step 3	5 minutes	5 minutes later, power off
	10 minutes	10 minutes later, power off
	20 minutes	20 minutes later, power off
	30minutes	30 minutes later, power off

OFF

[APO]off

Tips: Timer will be reset when press any keys or touch screen.

7. RemoteControl

This chapter provides the following information to remotely control the JK802/804/808 via the USB interface.

USB-HID

The USB-Serial Interface allows you to connect JK802 /804/808 to a USB port on you PC.
You needn't to install a driver in Windows system.

Figure7-1 The Jinko USB logo in windows device manager



Programming guide

The instrument goes along with data communication and acquisition software. You can also go to our website: www.jk17.com to download.

If you want to program the software by yourself, you need to know some basic knowledge about USB and USB-HID. Go to www.usb.org to find out more.

Basic API functions:

```
CreateFile( devDetail-
>DevicePath,
ENERIC_READ | GENERIC_WRITE,
FILE_SHARE_READ | FILE_SHARE_WRITE,
NULL,
OPEN_EXISTING,
FILE_FLAG_OVERLAPPED
, NULL);
```

Use CreateFile to open HID equipment, equipment communication channels can be found through functionSetupDiGetInterfaceDeviceDetail.

```
ReadFile( h
Dev,
```

recvBuffer,

```
IN_REPORT_LEN,
&recvBytes,
&ol);
```

Use ReadFile to read HID equipment. Report based on the data transferred from IN.

```
WriteFile( hD
ev,
reportBuf, OUT_REPORT_LEN,
&sendBytes,
&ol);
```

WriteFile is used to transfer an output report to HID equipment.

Communication

Parameters VIP:0825

PID:0826

Packet size:64bits

Any problems in programming, please contact our tech department, you can send an email to 5117jk17@163.com.

Tips

:

USB is always available, you needn't set any

parameters.

Command set

Command packet

Use 64 bits/pack to transfer data; every USB-HID command is 1 pack.

Command packets have a fixed format, the user must follow the format agreed by the instrument of writing, and otherwise it is

Tips

:

impossible to establish communication.

The command word is case-insensitive.

Each command packet contains the first 60 bytes of checksum, fill in the last four bytes.

PC command pack format(a C language-defined pack structure):

```
#define program pack(1)
typedef __packed struct
{
uint cSize; //packet size 4bytes =60
char sHeader[24]; //command 24bytes
char sPara[28]; //parameter 28bytes
uint nSignature; //signature 4bytes
uint nChecksum; //Checksum 4bytes
} TUSB_CMD;
```

```
#define program pack()
```

Here,

cSize: 60
 nSignature: 0x88805550
 sCmd,sPara: reference at
 SCPI set nChecksum:
 32 checksum

A complete send command pack(from PC) as follows: cSize: 0x0000003C,
 sHeader:
 IDN? sPara:
 (blank
)
 nSignature:
 0x8880555
 0 nChecksum:
 0x00002BC1

As command pack format and number of bits are fixed, so command words and parameters which are not qualified with the specified number of bytes must be filled hexadecimal. HEX:0x00.

Table 7-1A complete command pack in Hex format.

0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
00	00	00	40	49	44	4E	3F	00	00	00	00	00	00	00	00
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
00	00	00	00	00	00	00	00	88	80	55	50	00	00	2B	C1

Instrument response pack is 64 bytes, not sufficient for 0x00fill out.
 (Not ASCII"0")

A response pack (from instrument):

ASCII format: JK802,REV A1.0,00000000,Jinko Instruments Inc.

To test instrument USB-HID, we have free "Jinailian HID communication tester" software, you can download from:www.jk17.com

Notation Conventions and Definitions

A definition is not a part of a command, just used in interpretation and is not included in transfer.

The following conventions and definitions are used in this chapter to describe

USB-HID operation

Table7-2 Notation Conventions and
Definitions

<>	Name of a parameter
[]	The content is optional
	Select from several options

Parameter types

Parameters may be of four types as follows.

Table7-3 Available data type

Format		Samples
<NR1>	Integer	100,+100,-100
<NR2>	Rational	1.23,+1.23,-1.23
<NR3>	Floating-point	1.23E4,+1.23E4,-1.23E4,-1.23e-4
<NR4>	Floating-point with magnificatio	1.23K,1.23N,1.23U (magnification in following Table)

Table7-4 Magnification

Definition	Suffix
1E18 (EXA)	EX
1E15 (PETA)	PE
1E12 (TERA)	T
1E9 (GIGA)	G
1E6 (MEGA)	MA
1E3 (KILO)	K
1E-3 (MILLI)	M
1E-6 (MICRO)	U
1E-9 (NANO)	N
1E-12 (PICO)	P
1E-15 (PEMTO)	F
1E-18 (ATTO)	A

Command Reference

All commands in this reference are fully explained and listed in the following functional command order.

MODEL	Model subsystems
BEEP	Beep subsystem
RATE	Rate subsystem
UNIT	Unit subsystem
CHANON	Chanon subsystem
HIGH	High subsystem
LOW	Low subsystem
FETC?	Fetc? subsystem
IDN?	Version check
RST	Hot start subsystem

ERR Error subsystem

MODELSubsystem

model <tc-t|tc-k|tc-j|tc-n|tc-e|tc-s|tc-r|tc-b>

	To set the model
sHead	Model
sPar	<tc-t tc-k tc-j tc-n tc-e tc-s tc-r tc-b>

model?

	To check the current model
sHead	Model?
sPar	
Response	<tc-t tc-k tc-j tc-n tc-e tc-s tc-r tc-b>

BEEPSubsystem

beep <on|off>

	To set the beep
sHead	Beep
sPar	<on off>

beep?

	To check the current beep
sHead	beep?
sPar	
Response	<on off>

RATESubsystem

rate<slow|med|fast>

	To set the rate
sHead	Rate
sPar	<slow med fast>

rate?

	To check the current rate
sHead	rate?
sPar	
Response	<slow med fast>

UNIT SubSystem

unit<unit-c|unit-k|unit-f>

	To set the unit
sHead	Unit
sPar	<unit-c unit-k unit-f>

unit

?	To check the current unit
---	---------------------------

sHeader	Unit?
sPara	
Response	<(°C) (K) (F)>

CHANON SubSystem

Chanon<integer>

	To set the channel status
sHead	chanon
sPar	<integer> 8-bit data , each bit representing a channel 0: off 1: Open Example: 11111110 , channel 1 is closed , 2 to 8 channels is

chanon?

	To check the current channel status
sHead	chanon?
sPar	
Response	<integer>

HIGH SubSystem

high<float>

	To set upper limit
sHead	High
sPar	<float>

high?

	To query current upper limit
sHead	High?
sPar	
Response	<float>

LOWSubSystem

low<float>

	To set low limit
sHead	Low
sPar	<float>

low?

	To query current low limit
sHead	low?
sPar	
Response	<float>

FETC? SubSystem

FETC

	To query test result
--	----------------------

sHeader	FETC?
sPara	
Response	<float,float,float,float,float,float,float,float> RET>28.0,27.9,28.1<NL>

SYST System SubSystem

SYST:KEYL <ON | OFF | 1 | 0>

	To lock/unlock keypad and touch screen
sHead	SYST:KEYL
sPar	<ON OFF 1 0>

Tips: When the keypad and screen is locked, press[HOLD]to unlock ! Power key cannot be locked

IDN Subsystem

IDN

	To check version information
sHead	IDN?
sPar	
Response	JK802,REV A1.0,<Serial Number>,Jinko Instruments Inc.

RST Subsystem

RST

	To start in heat
sHead	RST
sPar	

Error Subsystem

ERR

	To check the message sent previously
sHead	ERR?
sPar	
Response	In the following Table

Table 7-5The Error Code and message

0, No error
1, Bad command
2, Parameter error
3, Missing parameter
4, Invalid multiplier
5, Numeric data error
6, Value too long

7, Invalid command

8. Specification

This chapter describes the specifications and supplemental performance characteristics of the JK802/804/808:

Specifications
Dimension

General Specification

The Data is Achieved under the Following Conditions:

Temperature: $23^{\circ}\text{C}\pm 5^{\circ}\text{C}$

Humidity: 65% R.H.

Warm-up Time: >60 minutes

Calibration Time :

12months Test Environment:

Temperature and humidity range: $15^{\circ}\text{C}\sim 35^{\circ}\text{C}$, 80% RH or less

Storage temperature and humidity range: $10^{\circ}\text{C}\sim 40^{\circ}\text{C}$, 10~90% RH

Thermocouple Type:

T,K,J,N,E,S,R,

B Display: 5 digits

Test Speed: Fast, Medium, Slow

Max Reading: 1800.0°C

Min Reading: -200.0°C

Beep: ON/OFF

Interface: USB-

HID Program Language: SCPI

Auxiliary Function: Keypad Lock

Accuracies

Instrument Accuracy does not include the standard contact compensation Precision.

Model	Range (°C)	Accuracy (°C)
T	-150°C to 0°C	±1.0°C
	0°C to 400°C	±0.8°C
K	-100°C to 0°C	±1.2°C
	0°C to 1350°C	±0.8°C
J	-100°C to 0°C	±1.0°C
	0°C to 1200°C	±0.7°C
N	-100°C to 0°C	±1.5°C
	0°C to 1300°C	±0.9°C
E	-100°C to 0°C	±0.9°C
	0°C to 850°C	±0.7°C
S	0°C to 100°C	±4.5°C
	100°C to 300°C	±3.0°C
	300°C to 1750°C	±2.2°C
R	0°C to 100°C	±4.5°C
	100°C to 300°C	±3.0°C
	300°C to 1750°C	±2.2°C
B	600°C to 800°C	±5.5°C
	800°C to 1000°C	±3.8°C
	1000°C to 1800°C	±2.5°C

Standard connection compensation need to add ±0.5°C based on thermocouple measuring accuracy.

The measuring accuracy of thermocouple sensor gives priority to sensor supplier's standard.

Dimension



Jinko Instruments
Changzhou
Jinailian Electronic Technology
Co.,Ltd
JK802804/808
User's Manual
English Edition